

Charging procedure AXIWI®

- Switch the AXIWI's off when they need to be charged, press the power button for about 2 seconds, all the lights of the AXIWI will be turned off.
- Check if the charger is not connected to the power line,
- Place the AXIWI's in the charger, check if the AXIWI's are clicked well in the charger,
- Connect the charger to the power line. All the 'S' buttons will glow red. The 'S' button will glow green after the AXIWI's are completely charged. The AXIWI's are fully charged after 2 till 3 hours,
- The charger has to be turned off and removed from the socket. After this the AXIWI's can be removed from the charger,
- Do not remove the AXIWI's from the charger while charging.